

Flying Operations

C-17 OPERATIONS PROCEDURES

COMPLIANCE WITH THIS PUBLICATION IS MANDATORY

NOTICE: This publication is available digitally on the AFPDO WWW site at: http://afpubs.hq.af.mil.

OPR: HQ AMC/A3V (Maj Marvin L. Fisher) Supersedes AFI 11-2C-17, Vol 3, 1 December 1999, Certified by: HQ USAF/XOO (Maj Gen Teresa M. Peterson)
Pages: 360

Distribution: F

This instruction implements AFPD 11-2, *Aircraft Rules and Procedures*. It establishes policy for the operation of the C-17 aircraft to safely and successfully accomplish their worldwide mobility missions. The use of the name or mark of any specific manufacturer, commercial product, commodity, or service in this publication does not imply endorsement by the Air Force. This instruction applies to Air Force Associate Reserve (AFRC) units and Air National Guard (ANG) units.

The Privacy Act of 1974 affects this instruction. The Privacy Act System Number F011 AF XO A, Air Force Operations Resource Management System (AFORMS) covers required information. The Paper Reduction Act of 1974 as amended in 1996 affects this instruction. Maintain and dispose of records created as a result of processes prescribed in this publication in accordance with AFMAN 37-139, *Records Disposition Schedule*.

SUMMARY OF REVISIONS:

Change 1 to AFI 11-2C-17 Volume 3, 1 January 2001, adds a reference to AFI 11-2C-17V3, ADDENDA B, *C-17 Special Operations* and associated checklists. **POSTING INSTRUCTIONS:** Users should print Change 1 using duplex head-to-head printer settings and replace the appropriate pages. Change 1 replaces pages 1-2.

Change 2 to AFI 11-2C-17 Volume 3, 1 January 2004, removes and replaces chapter 4, *Aircraft Operating Restrictions*, and chapter 24, *Night Vision Goggle Operations (NVG)* in their entirety.

This instruction contains references to Air Mobility Command (AMC) and Multicommand (MC) Forms, which, until converted to departmental level publications and forms, may be obtained from the AMC publications' web home page or from the AMC Publishing Office:

Publications: AMCI 11-301, AMCMAN 11-211, AMCP 55-25, AMCRs 3-2V2, 28-2, 55-18, 55-20, 55-25, 55-79, and AMCVA 36-2206.

Forms: AMC Forms 38, 41, 43, 54, 97, 148, 181, 196, 305, and 423.

AFI 11-2C-17V3,	ADDENDA A,	Configuration	and Mission	Planning

SUPPORTING CHECKLISTS:

	AFI 11-2C-17V3CL1,	Formation Air	Refueling	Procedures
--	--------------------	---------------	-----------	------------

AFI 11-2C-17V3CL2, C-17 Loadmaster Passenger Briefings

AFI 11-2C-17V3CL3, Pilot Combat Operations Guide

AFI 11-2C-17V3CL4, Loadmaster Combat Checklists

AFI 11-2C-17V3CL5, C-17 Pilot Airdrop Briefing Guides and Checklists

AFI 11-2C-17V3CL6, C-17 Loadmaster Airdrop Checklists

AFI 11-2C-17V3CL7, Mission Briefing Guides

AFI 11-2C-17V3CL8, Preflight and Post Mission AEC Checklist

Chapter 1—GENERAL INFORMATION	24
1.1. General	24
1.2. Applicability	24
1.3. Key Words Explained	24
1.4. Deviations and Waivers	24
1.5. Supplements	25
1.6. Requisition and Distribution Procedures	25
1.7. Improvement Recommendations	25
1.8. Definitions	25
1.9. Aircrew Operational Reports	25
Chapter 2—COMMAND AND CONTROL	26
2.1. General	26
2.2. Execution Authority	26
2.3. Aircraft Commander Responsibility and Authority	26
2.4. Mission Clearance Decision	27
2.5. Aircrew Responsibilities	27
2.6. Operational C2 Reporting	27

AFI	11-2C-17V3	(C2) 31	MARCH	2004

3

	2.7. Mission Commanders
	2.8. C2 Agency Telephone Numbers
	2.9. Close Watch Missions
	2.10. Posse Comitatus
Cl	hapter 3—CREW MANAGEMENT
	3.1. Aircrew Qualification
	3.2. Crew Complement
	Table 3.1. Crew Complement
	3.3. Scheduling Restrictions
	3.4. Alerting Procedures
	3.5. Stage Management
	3.6. Crew Duty Time (CDT) and Flight Duty Period (FDP)
	3.7. Crew Rest
	3.8. Standby Force Duty
	3.9. Orientation Flights and Incentive Flights
	3.10. Interfly
Cl	hapter 4—AIRCRAFT OPERATING RESTRICTIONS
	4.1. Objective
	4.2. Minimum Equipment List (MEL) Policy
	4.3. Waiver Protocol
	4.4. Technical Assistance
	4.5. MEL Table Definitions/Column Identifiers
	4.6. C-17 MEL
	4.7. Supplements
	4.8. Navigation Systems
	4.9. Gear Down Flight Operations
	Table 4.1. Air Conditioning/Pressurization
	Table 4.2. Anti-Ice
	Table 4.3. Equipment and Furnishings
	Table 4.4. Communications
	Table 4.5. Fire Protection

	Table 4.6. Electrical	31
	Table 4.7. OBIGGS	51
	Table 4.8. Flight Controls (Auto-Flight)	51.1
	Table 4.9. Fuel	51.2
	Table 4.10. Hydraulics	51.4
	Table 4.11. Indicating Systems	51.5
	Table 4.12. Landing Gear and Brakes	51.5
	Table 4.13. Lighting	51.6
	Table 4.14. Navigation Systems	51.7
	Table 4.15. Oxygen	51.8
	Table 4.16. Bleed Air	51.9
	Table 4.17. Cargo Mission Systems (Airland)	51.9
	Table 4.18. Cargo Mission Systems (Airdrop)	51.10
	Table 4.19. Doors	51.10
	Table 4.20. Engines/APU	51.12
	Table 4.21. Emergency Equipment	51.12
Ch	apter 5—OPERATIONAL PROCEDURES	52
Ch	tapter 5—OPERATIONAL PROCEDURES 5.1. Checklists	52 52
Ch		52
Ch	5.1. Checklists	52 52
Ch	5.1. Checklists	52 52 52
Ch	5.1. Checklists	52 52 52
Ch	5.1. Checklists	52 52 52 52
Ch	5.1. Checklists	525252525253
Ch	5.1. Checklists 5.2. Duty Station 5.3. Flight Station Entry 5.4. Takeoff and Landing Policy 5.5. Right Seat Procedures 5.6. Outside Observer	52525252525353
Ch	5.1. Checklists 5.2. Duty Station 5.3. Flight Station Entry 5.4. Takeoff and Landing Policy 5.5. Right Seat Procedures 5.6. Outside Observer 5.7. Seat Belts	525252525353
Ch	5.1. Checklists 5.2. Duty Station 5.3. Flight Station Entry 5.4. Takeoff and Landing Policy 5.5. Right Seat Procedures 5.6. Outside Observer 5.7. Seat Belts 5.8. Aircraft Lighting	 52 52 52 52 53 53 53
Ch	5.1. Checklists 5.2. Duty Station 5.3. Flight Station Entry 5.4. Takeoff and Landing Policy 5.5. Right Seat Procedures 5.6. Outside Observer 5.7. Seat Belts 5.8. Aircraft Lighting 5.9. Portable Electronic Devices	52 52 52 52 53 53 53 53
Ch	5.1. Checklists 5.2. Duty Station 5.3. Flight Station Entry 5.4. Takeoff and Landing Policy 5.5. Right Seat Procedures 5.6. Outside Observer 5.7. Seat Belts 5.8. Aircraft Lighting 5.9. Portable Electronic Devices 5.10. Smoking Restrictions	52 52 52 53 53 53 53 53
Ch	5.1. Checklists 5.2. Duty Station 5.3. Flight Station Entry 5.4. Takeoff and Landing Policy 5.5. Right Seat Procedures 5.6. Outside Observer 5.7. Seat Belts 5.8. Aircraft Lighting 5.9. Portable Electronic Devices 5.10. Smoking Restrictions 5.11. Advisory Calls	52 52 52 53 53 53 53 53 53
Ch	5.1. Checklists 5.2. Duty Station 5.3. Flight Station Entry 5.4. Takeoff and Landing Policy 5.5. Right Seat Procedures 5.6. Outside Observer 5.7. Seat Belts 5.8. Aircraft Lighting 5.9. Portable Electronic Devices 5.10. Smoking Restrictions 5.11. Advisory Calls 5.12. Communications Policy	52 52 52 53 53 53 53 53 53 54

	5.16. Aircraft Taxi Obstruction Clearance Criteria and Foreign Object Damage (FOD) Avoid
	5.17. Reverse Taxi
	5.18. Fuel Jettison Procedures
	5.19. Airspeed
	5.20. BASH Programs
	5.21. Functional Check Flights (FCF) and Acceptance Check Flights (ACF)
	5.22. Participation in Aerial Events
	5.23. TCAS
	5.24. Radar Altimeter
	5.25. Ground Proximity Warning System (GPWS) OR Ground Collision Avoidance System(GCAS)
	5.26. Buddy Start
	5.27. Not Used
	5.28. Aircraft Recovery From Unprepared Surfaces
	5.29. Not Used
	5.30. Use of Automation
	5.31. Standard AFCS Terminology
Chap	ter 6—AIRCREW PROCEDURES
Section	on 6A Pre-mission
	6.1. Aircrew Uniform
	6.2. Personal Requirements
	6.3. Pre-mission Actions
	6.4. Aircrew Publications Requirements
	Table 6.1. Aircrew Publications Requirements
Section	on 6B Pre-departure
	6.5. Airfield Certification
	6.6. Aircrew Intelligence Briefing
	6.7. Flight Crew Information File (FCIF) Procedures
	6.8. Flight Crew Bulletins (FCB) (As Applicable)
	6.9. Airfield Security
	6.10. Mission Kits

	6.11. Route Navigation Kits	68
	Table 6.2. Contents of Route Navigation Kit	68
	6.12. Briefing Requirements	68
	6.13. Call Signs	69
	6.14. Instrument Flight Rules	70
	6.15. Flight Data Verification	70
	6.16. Departure Planning	70
	6.17. Obstacle Clearance Planning	72
	Figure 6.1. Obstacle Clearance	73
	6.18. Alternate Planning	75
	6.19. Departure Alternates	75
	6.20. Destination Requirements	76
	6.21. Adverse Weather	76
	6.22. Fuel Conservation	77
Sect	tion 6C Preflight	77
	6.23. AFTO Form 781, AFORMS Aircrew/Mission Flight Data Document	78
	6.24. Aircraft Servicing and Ground Operations	78
	6.25. Aircraft Recovery Away from Main Operating Base (MOB)	79
	6.26. Life Support Requirements	79
	6.27. Fleet Service Equipment	80
	6.28. Cargo Documentation	80
	6.29. Procedures for Airlifting Hazardous Cargo	80
	6.30. Handling Of Classified Cargo, Registered Mail, NMCS/VVIP/FSS Shipments, a Courier Material	nd 83
Sect	tion 6D Departure	84
	6.31. On Time Takeoffs	84
	6.32. Weather Minimums For Takeoff	84
	Table 6.3. Weather Minimums	84
Sect	tion 6E En route	84
	6.33. Flight Progress	84
	6.34. Navigational Aid Capability	86
	6.35. CIRVIS and Other Reports	88
	6.36. In-Flight Meals	88

	6.37. Communications	88
	6.38. In-Flight Emergency Procedures	88
	6.39. Need for Medical Assistance	89
	6.40. Weather Forecasts	89
Sect	ion 6F Arrival	89
	6.41. Descent	89
	6.42. Instrument Approach Procedures	90
	6.43. Classified Equipment and Material	92
	6.44. Unscheduled Landings	93
	6.45. Maintenance	93
	6.46. Border Clearance	94
	6.47. Insect and Pest Control	95
Sect	ion 6G Miscellaneous	96
	6.48. Dropped Object Prevention	96
	6.49. Cockpit Voice Recorder (CVR)	96
	6.50. Life Support and Dash 21 Equipment Documentation	96
	6.51. C-17 HUD/MFD Endorsement	97
	6.52. Arresting Cables	97
	6.53. Airfield Data Reports	98
	6.54. Impoundment of Aircraft	98
	6.55. Cockpit Congestion and Loose Objects	98
	6.56. Overflying Enroute Stops	98
	6.57. Ordnance Procedures	98
Cha	pter 7—AIRCRAFT SECURITY	99
	7.1. General	99
	7.2. Security	99
	7.3. Air Force Physical Security Program	99
	7.4. En Route Security	99
	7.5. Detecting Unauthorized Entry	100
	7.6. Preventing and Resisting Hijacking	101
	7.7. Preventive Measures	101
	7 8 Initial Response	100

7.9. In-Flight Resistance	102
7.10. Communications Between Aircrew and Ground Agencies	103
7.11. Forced Penetration of Unfriendly Airspace	104
7.12. Arming of Crew members	104
7.13. Force Protection	105
7.14. Protecting Classified Material on Aircraft	107
Chapter 8—OPERATIONAL REPORTS AND FORMS	108
8.1. General	108
8.2. AF Form 457, USAF Hazard Report	108
8.3. AF Form 651, Hazardous Air Traffic Report (HATR)	108
8.4. AF Form 711, USAF Aircraft Mishap Report Worksheet (Aircraft and Pe Mishaps)	
8.5. Reports of Violations/Unusual Events or Circumstances	110
8.6. Petroleum, Oil, and Lubricants (POL)—Aviation Fuels Documentation	111
8.7. AMC Form 54, Aircraft Commanders Report on Services/Facilities	113
8.8. AMC Form 43, AMC Transient Aircrew Facilities Report	114
8.9. AMC Form 196, Aircraft Commander's Report on Crew member	114
8.10. AMC Form 423,MIJI (Meaconing, Intrusion, Jamming,Interference) Inc Report Worksheet	
8.11. DD Form 1748-2, Airdrop Malfunction Report (Personnel-Cargo)	114
8.12. AF Form 4096, Airdrop/Tactical Airland/Air Refueling Mission Recap, S Debrief	
Chapter 9—TRAINING POLICY	115
9.1. Qualification Training	115
9.2. Not used	115
9.3. Touch and Go Landing Limitations	115
9.4. Simulated Emergency Flight Procedures	116
9.5. Copilot Air Refueling Training	116
9.6. Operating Limitations	110
9.7. Not Used	117
9.8 Prohibited In-Flight Maneuvers	113

1111 11-2C-17 V5 (C2) 51 WIMMC11 200	AFI 11-2C-17V3 (C
--------------------------------------	-------------------

\sim
•
_

9.9. Instructor Pilot Briefing	117
9.10. Debriefing	117
9.11. Simulated Instrument Flight	117
Table 9.1. Flight Restrictions	117
Chapter 10—LOCAL OPERATING PROCEDURES	119
10.1. Units define local operations procedures in this chapter	119
Chapter 11—NAVIGATIONAL PROCEDURES	120
Section 11A General	120
11.1. Flight Planning	120
11.2. En Route	120
11.3. Post Flight	121
Section 11B Mission Computer Directed Approach Procedures	121
11.4. General	121
11.5. Restrictions	121
11.6. Planning the Approach	122
11.7. Planning the Missed Approach Segment	123
11.8. Flying the Approach	123
Chapter 12—AIRCREW MAINTENANCE SUPPORT TASKS	124
12.1. General	124
12.2. Authority to Clear a Red X	124
12.3. Refueling/Defueling	124
12.4. Fault Reporting Manual	124
12.5. Maintenance Interface Panel	124
12.6. Maintenance Monitor Panel	124
12.7. Aircraft Servicing Requirements	124
Table 12.1. Job Guides	125
Chapter 13—LOADMASTER PROCEDURES	126
13.1. General	126
13.2. Responsibilities for Aircraft Loading	126

	13.3. Emergency Exits and Safety Aisles
	13.4. Air Cargo Restraint Criteria
	13.5. Preflight Duties
	13.6. Passenger Handling
	13.7. Over-Packed Meal Procedures
	13.8. En Route and Post-Flight Duties
	13.9. Emergency Airlift of Personnel
	13.10. Weight and Balance
	13.11. Loaded Weapons
	13.12. Cargo Validation Onloading and Offloading Procedures
Chap	oter 14—FUEL PLANNING
Section	on 14A General Procedures
	14.1. General
	14.2. Fuel Planning Profiles
	14.3. Fuel Conservation
	14.4. General Fuel Planning Procedures
	14.5. Airland Fuel Planning
	14.6. Air Refueling (AR) Fuel Planning
	14.7. Tactical Fuel Planning
Section	on 14B Airland Fuel Planning
	Figure 14.1. Airland Fuel Planning (part 1 of 6)
	Figure 14.2. Airland Fuel Planning (part 2 of 6)
	Figure 14.3. Airland Fuel Planning (part 3 of 6)
	Figure 14.4. Airland Fuel Planning (part 4 of 6)
	Figure 14.5. Airland Fuel Planning (part 5 of 6)
	Table 14.1. Extra Fuel Planning for Airland
	Figure 14.6. Airland Fuel Planning (part 6 of 6)
Section	on 14C Air Refueling (A/R) Fuel Planning
	Figure 14.7. Air Refueling (A/R) Fuel Planning (part 1 of 13)
	Figure 14.8. Air Refueling (A/R) Fuel Planning (part 2 of 13)
	Figure 14.9. Air Refueling (A/R) Fuel Planning (part 3 of 13)
	Figure 14.10. Air Refueling (A/R) Fuel Planning (part 4 of 13)

,	Table 14.2. Identified Extra Fuel Planning for Air Refueling
]	Figure 14.11. Air Refueling (A/R) Fuel Planning (part 5 of 13)
,	Table 14.3. Air Refueling Fuel Planning Steps
]	Figure 14.12. Air Refueling (A/R) Fuel Planning (part 6 of 13)
]	Figure 14.13. Air Refueling (A/R) Fuel Planning (part 7 of 13)
]	Figure 14.14. Air Refueling (A/R) Fuel Planning (part 8 of 13)
,	Table 14.4. Identified Extra Fuel Planning for Air Refueling
]	Figure 14.15. AirRefueling (A/R) Fuel Planning (part 9 of 13)
,	Table 14.5. Air Refueling Fuel Planning Steps Example
]	Figure 14.16. Air Refueling (A/R) Fuel Planning (part 10 of 13)
]	Figure 14.17. Air Refueling (A/R) Fuel Planning (part 11 of 13)
]	Figure 14.18. Air Refueling (A/R) Fuel Planning (part 12 of 13)
,	Table 14.6. Identified Extra Fuel Planning #3.
]	Figure 14.19. Air Refueling (A/R) Fuel Planning (part 13 of 13)
Section	on 14D Tactical Fuel Planning
]	Figure 14.20. Tactical Fuel Planning (part 1 of 2)
]	Figure 14.21. Tactical Fuel Planning (part 2 of 2)
Chap	ter 15—AIR REFUELING
	15.1. AR Limitations
	15.2. Receiver Aircraft Commander Responsibilities
-	15.3. ATC Clearance
	15.4. Communications Failure
	15.5. MARSA Applicability for Aerial Refueling
	15.6. Operational Reporting
Chap	ter 16—COMBAT MISSION PLANNING
-	16.1. General
	16.2. Mission Planning
	Table 16.1. SKE Frequency De-confliction
	16.3. Crew Mission Study and Detailed Flight Planning
	Table 16.2. Radar Horizon Distance (RHD)Nautical Miles (NM)
	Figure 16.1. Detection Free Altitude

	Figure 16.2. Inherent Chart Errors
	Figure 16.3. Night VMC Enroute Altitude
	Figure 16.4. IMC Drop Profile
	Table 16.3. IMC Drop Profile Calculation
	Table 16.4. Slowdown Distance (part 1 of 3)
	Table 16.5. Slowdown Distance (part 2of 3)
	Table 16.6. Slowdown Distance (part 2of 3)
	Figure 16.5. Chart Annotation and Symbols
	Figure 16.6. Recovery Arrow Box
	Figure 16.7. Course Line Annotations
	Figure 16.8. Time and Distance Mark Annotations
	Figure 16.9. Combat Entry (CEP) or Exit Point Annotations
	Figure 16.10. Navigation Information Block Annotations
	Figure 16.11. Operational Advisory Arrows Annotations Examples
	16.4. Airlift Support Forces Coordination
	16.5. Briefings
	16.6. Mission Debriefings
	ion 17A General Procedures 17.1. General
	17.2. Passengers on Tactical Flights
	17.3. Restrictions
	17.4. Communications
	17.5. Airfield and ALZ Requirements
	17.6. Tactical Checklists
	17.7. Rear Vision Device (RVD)
	17.8. Energy Management
Sect	1 / .U. Diloi = v ivialia = cilicii
	ion 17B En Route Procedures
	ion 17B En Route Procedures 17.9. Planning
Sect	ion 17B En Route Procedures 17.9. Planning
Sect	ion 17B En Route Procedures 17.9. Planning

17.12. Tactical Descents	
17.13. Low Altitude Approaches	
Figure 17.1. Pop Up Maneuver	
17.14. High Altitude Approaches	
17.15. Steep Approaches	
17.16. Departure Procedures General	
Section 17D Ground Operations	
17.17. General	
17.18. Loading of Rucksacks	
17.19. Engine Running Onload and Offload (ERO) Procedures	
17.20. Combat Offload Procedures	
17.21. Emergency Airlift of Personnel	
17.22. Expanded Combat Entry Checklist	
Table 17.1. Expanded Combat Entry Checklist	
Table 17.2. Expanded Combat Exit Checklist	
17.23. Loadmaster Combat Offload Preparation Checklist	
Table 17.3. Loadmaster Combat Offload Preparation Checklist	
17.24. Expanded Combat Offload Checklist	
Table 17.4. Combat Offload Checklist	
Chapter 18—AIRCRAFT FORMATION	
Section 18A General Procedures	
18.1. General	
18.2. Specified Times	
18.3. Weather Minimums	
18.4. Ground Operations	
18.5. Takeoff	
18.6. Altimeter Setting	
18.7. Bank Angles, Airspeeds, and Rates of Ascent/Descent	
Table 18.1. Bank Angles, Airspeeds, and Rates of Ascent/Descent	
18.8. Radio Discipline	
18.9. Airborne Aborts (Departure, Enroute and Element Lead Abort	
18.10. Not Used	

18.11. Not Used	21
18.12. Forms	21
18.13. Not Used	21
Section 18B Visual Procedures	21
18.14. General	21
18.15. Departure and Assembly	21
18.16. Acceleration	21
18.17. Late Take Off	21
18.18. En Route Procedures	21
Figure 18.1. Inadvertent Weather Penetration Without SKE	21
18.19. Not used	21
18.20. Not used	21
18.21. Not used	21
18.22. Recovery	21
18.23. Formation Landings	21
18.24. Lead Changes	22
18.25. Orbit For Rejoin	22
18.26. Visual Formation Geometries	22
Figure 18.2. Fluid Trail	22
Figure 18.3. Modified "V"	22
Figure 18.4. Box	22
Figure 18.5. Inverted Vic	22
Figure 18.6. Visual In-Trail	22
Section 18C SKE Procedures	22
18.27. General	22
18.28. SKE Operating Procedures	22
18.29. Departure and Assembly	22
18.30. Late Takeoffs and SKE Rejoins	22
18.31. En Route Procedures	22
Figure 18.7. Standard SKE Enroute Formation	22
18.32. Spacing	22
18.33. Loss of SKE	22
18.34. Overrun Procedures	22

	18.35. Lead SKE Position Change
	18.36. Not Used
	18.37. Not Used
	18.38. Not Used
	18.39. Not Used
	18.40. Not Used
	18.41. Not Used
	18.42. Not Used
	18.43. Not Used
	18.44. Not Used
	18.45. Recoveries
	18.46. Not Used
	18.47. Not Used
Sect	tion 18D Combination SKE And Visual Procedures
	18.48. General
Sect	tion 18E Formation Air Refueling Procedures
	18.49. General
	18.50. Briefing
	18.51. Terms
	18.52. Preflight Procedures
	18.53. Prior to Air Refueling Initial Point (ARIP)
	18.54. Rendezvous Procedures
	18.55. Transition to AR Echelon
	18.56. Refueling Operations
	18.57. Refueling Complete
	18.58. Re-assembly Procedures
	18.59. Emergency Actions
Cha	apter 19—AIRDROP
Sect	tion 19A General Procedures
	19.1. General
	19.2. Identification of Airdrop Items
	19.3. Airdrop Kits

	19.4. Joint Airdrop Inspection
	Table 19.1. Airdrop Loads With Airland Cargo
	19.5. Verification of Load Information
	19.6. Marking Airdrop Loads
	19.7. Drop Zone Markings
	19.8. Night Vision Goggles
	19.9. Safety Equipment
	19.10. Not Used
	19.11. Airdrop Weather
	19.12. Forms
Sect	ion 19B Flight Procedures
	19.13. General
	19.14. Airdrop Checklists
	19.15. En Route
	Figure 19.1. Slowdown Maneuver
	19.16. Airdrop Altitudes and Airspeeds
	19.17. Drop Zone Communications
	19.18. Navigating to the Release Point
	19.19. No Drop Decisions
	19.20. Drop Zone Escape Procedures
	19.21. Drop Zone Race Track Procedures
Sect	ion 19C Methods of Aerial Delivery
	19.22. General
	19.23. Auto Airdrops
	19.24. Pilot-Directed Airdrops (PDA)
	19.25. Ground Marked Release System (GMRS)
	19.26. Verbally Initiated Release System (VIRS)
	19.27. Jumpmaster Directed Airdrops (JDA)
	19.28. Zone Marker (ZM) Airdrops
	19.29. Not Used
	19.30. Radar Beacon Airdrops (RBA)
	19.31. Ground Radar Aerial Delivery System (GRADS)
	19.32. Not Used

19.33.	GPS Airdrop
Section 19D	High Altitude Airdrop Procedures
19.34.	General
19.35.	Preflight
19.36.	Oxygen Requirements
Table 1	9.2. High Altitude Airdrop Pre-breathing Requirements
19.37.	Aircrew Requirements
19.38.	Physiological Technician (PT) Requirements
19.39.	Physiological Technician (PT) Duties
19.40.	Conduct Of Operations
19.41.	High Altitude Personnel Airdrop Procedures
19.42.	High Altitude Container Delivery System
Section 19E	Airdrop Load Information
19.43.	Personnel Airdrops
19.44.	Not Used
19.45.	Not Used
19.46.	Combination Airdrops
19.47.	90/270 Maneuver
19.48.	Door Bundle Airdrops
19.49.	Heavy Equipment Airdrops
19.50.	Container Delivery System (CDS) Airdrops
19.51.	Not Used
19.52.	Combat Rubber Raiding Craft (CRRC) Airdrops
19.53.	Free Fall Airdrops
19.54.	Not Used
19.55.	Not Used
Section 19F	Emergency Procedures
19.56.	General
19.57.	Emergency Parachutist Bailout Procedures
19.58.	Towed Parachutist
19.59.	Heavy Equipment Emergency Procedures
19.60.	CDS Emergency Procedures
19.61.	CRRC Emergency Procedures

19.62. Not U	Jsed	263
19.63. Not U	Jsed	263
19.64. High	Altitude Emergency Procedures	264
Section 19G Amp	olified Airdrop Checklists	264
	rewmembers should be familiar with all amplified checklist procedures prior the abbreviated annexes	r to 264
Section 19H Aird	rop Formation Procedures	264
19.66. Gene	ral	264
19.67. En R	oute Spacing	264
19.68. Visua	al Formation Slowdowns	264
19.69. SKE	Formation Slowdowns	265
19.70. SKE	Drift Offset	266
19.71. Clear	rance to Drop	266
19.72. No-D	Prop Decisions	266
19.73. Form	ation Airdrop Execution	266
19.74. Visua	al Formation DZ Escape	267
19.75. SKE	Formation DZ Escape	267
19.76. Aircr	raft Aborts (Airdrop)	268
19.77. Reco	vering Large Formations	268
19.78. Over	run Procedures	268
19.79. Rend	ezvous	268
19.80. Multi	iple Points of Impact (MPI)	269
19.81. Perso	onnel Formation Airdrop Procedures	269
Section 19I Mixed	d Formation Airdrop Procedures	271
19.82. C-17	/C-130 Mixed Formations	271
19.83. C-17	/C141 Mixed Formations	271
Figure 19.2.	Personnel Airdrop Geometry	272
Figure 19.3.	Offset Points of Impact	273
Figure 19.4.	Personnel Formation Drift Table	274
19.84. AMP	LIFIED AIRDROP CHECKLIST	274
19.85. CAB	IN ALTITUDE CHECKLIST	274
Table 19.3.	Cabin Altitude Checklists	275
19.86. PRE-	SLOWDOWN CHECKLIST	276

Та	able 19.4. Pre-Slowdown Checklists
19	9.87. SLOWDOWN CHECKLIST
Та	able 19.5. Slowdown Checklists
19	9.88. RELEASE POINT CHECKLIST
Та	able 19.6. Release Point Checklists
Та	able 19.7. Post Drop Checklists
19	0.89. LOADMASTER'S MALFUNCTION CHECKLISTS
Та	able 19.8. Malfunction Checklists
Chapte	r 20—AEROMEDICAL EVACUATION
Section	20A General Information
20	0.1. Mission
20	0.2. Not Used
20	0.3. Waivers and Revisions
20	0.4. Not Used
Section	20B Aeromedical Evacuation Command and Control
20	0.5. Operational Control and Reporting of Aeromedical Evacuation Forces
20	0.6. Aircraft Commander Responsibilities
20	0.7. Flight Crew Responsibilities
20	0.8. Aeromedical Evacuation Crew Responsibilities
20	9.9. Patient Death In-Flight
Section	20C Aeromedical Evacuation Crew Complement and Management
20	0.10. Aeromedical Evacuation Crew Complement
20	0.11. Aeromedical Evacuation Crew Management
Section	20D Aeromedical Evacuation Aircrew Procedures
20	0.12. Checklists
Section	20E Aeromedical Evacuation Airlift Operations
20	0.13. General
20	0.14. En Route Diversions
20	0.15. Ground Operations
20	0.16. Refueling Operations
20	0.17. Aircraft Pressurization
20	0.18. Aircraft Configuration

2	20.19. Passengers and Cargo
2	20.20. Crash/Fire/Rescue
2	20.21. AE Call Sign/Use of Priority Clearance
2	20.22. Load Message
2	20.23. Change in Patient Status
Section	n 20F Contingency Operations
2	20.24. Engine Running Onload (ERO) Procedures
2	20.25. Floor Loading Procedures
2	20.26. Aerial Refueling (AR)
Chapt	er 21—INTENTIONALLY LEFT BLANK
-	21.1. This chapter is reserved for future C-17 operations (Search and Rescue)
Chapt	er 22— EMERGENCY NUCLEAR AIRLIFT (ENAF)
Section	n 22A Mission Preparation
2	22.1. Emergency Nuclear Airlift
2	22.2. Conduct of Operations
2	22.3. Emergency Nuclear Airlift Standards
2	22.4. Aircrew Selection
2	22.5. Aircrew Requirements
2	22.6. Aircrew Briefings
2	22.7. Emergency Mission Kit
Section	n 22B En Route Procedures
2	22.8. General
2	22.9. Custody of Nuclear Cargo
2	22.10. Security Procedures
2	22.11. Emergency Procedures
2	22.12. Maintenance on Aircraft Loaded with Nuclear Cargo
Section	n 22C Emergency Nuclear Airlift Operations Guide
2	22.13. General
2	22.14. Prior to Onload
2	22.15. Arrival and Onload
2	22.16. En Route to Offload

	22.17. Offload	
Cha	apter 23—AIRCREW CHEMICAL OPERATIONS AND PROCEDURES	
	23.1. Wear of Aircrew Chemical Defense Ensemble (ACDE)	
	23.2. Factors Influencing the Chemical Warfare (CW) Agent Hazard	
	23.3. Categories of Chemical Warfare Agents	
	23.4. Nerve Agents	
	23.5. Blister Agents	
	23.6. Choking Agents	
	23.7. Blood Agents	
	23.8. Aircrew Operations	
	23.9. Limitations	
	23.10. ACDE Issue	-
	23.11. Operations in a Chemical-Biological Threat Area (CBTA)	
	23.12. Donning Equipment	
	23.13. Ground Operations	
	23.14. Chemical Attack During Ground Operations	
	23.15. Crew Rest Procedures	
	23.16. Outbound with Actual/Suspected Chemical Contamination	
	23.17. Communicating Down-line Support	
	23.18. Contamination Control Areas (CCA) Procedures	
	23.19. Work Degradation Factors	
	Table 23.1. Task Time Multipliers	
Cha	apter 24—NIGHT VISION GOGGLE OPERATIONS (NVG)	
	24.1. General	· -
	24.2. Training/Operations	-
	24.3. Mission Planning	
	24.4. Weather Minimums	
	24.5. Minimum Operational Equipment	
	24.6. Aircraft Preparation	•
	24.7. Aircraft Lighting	
	24.8. NVG Donning/Doffing Procedures	

	24.9. NVG Enroute Procedures	323
	24.10. NVG Airland	323
	24.11. NVG Airdrop Procedures	324
	24.12. NVG Formation Procedures	325
	24.13. NVG Emergency Procedures	325
	24.14. Aircraft Preparation	326
Ch	apter 25—NAVAL EMERGENCY AIR CARGO DELIVERY SYSTEM (NEACDS	S) 330
	25.1. General	330
	25.2. NEACDS Operational Requirements	330
	25.3. Mission Planning	330
	25.4. Search Procedures	331
	Figure 25.1. Expanding Square	333
	Figure 25.2. Creeping Line Pattern	334
	25.5. Procedures	334
	Figure 25.3. NEACDS En Route Profile	336
	Figure 25.4. Time from Rendezvous to First Turn	337
	Table 25.1. Average Group speed - Rendezvous to First Turn	337
	Table 25.2. Time Abeam Ship to Turn Inbound/Outbound Groundspeed	337
	Figure 25.5. NEACDS CARP	339
	25.6. NEACDS Radio Worksheet	339
	25.7. Operational Brevity Codes are Table 25.1.	340
	Table 25.3. Operational Brevity Codes	341
	25.8. Forms Prescribed	343
Att	cachment 1-GLOSSARY OF REFERENCES AND SUPPORTING INFORMATION	N 344

THIS PAGE INTENTIONALLY LEFT BLANK

Chapter 1

GENERAL INFORMATION

1.1. General.

- 1.1.1. This AFI provides guidelines for C-17 operations and applies to Air Force C-17 aircrews and all management levels concerned with operation of the C-17. It is a compilation of information from aircraft flight manuals, FLIP publications, and other Air Force directives, as well as an original source document for many areas. When specified as the reference, the basic source directive has precedence in the case of any conflicts, revisions, and matters of interpretation. For those areas where this AFI is the source document see paragraph 1.4. for the appropriate waiver authority. Where areas of this AFI repeats information in other source documents, waiver authority will be in accordance with these source documents.
- 1.1.2. All units and agencies involved in or supporting C-17 operations will use this AFI. Copies will be current and available to planning staffs from headquarters to aircrew level. Maintain a copy of this AFI at mobility transportation and base operations passenger manifesting agencies.
- **1.2. Applicability.** This AFI is applicable to all individuals and units operating C-17 aircraft. Copies should be available to all aircrew members operating the C-17.

1.3. Key Words Explained.

- 1.3.1. "Will" and "shall" indicate a mandatory requirement.
- 1.3.2. "Should" is normally used to indicate a preferred, but not mandatory, method of accomplishment.
- 1.3.3. "May" indicates an acceptable or suggested means of accomplishment.
- 1.3.4. "Note" indicates operating procedures, techniques, etc., which are considered essential to emphasize.
- 1.3.5. "Caution" indicates operating procedures, techniques, etc., which could result in damage to equipment if not carefully followed.
- 1.3.6. "Warning" indicates operating procedures, techniques, etc., which could result in personal injury or loss of life if not carefully followed.
- **1.4. Deviations and Waivers.** Do not deviate from the policies and guidance in this AFI except for safety, or when necessary to protect the crew or aircraft from a situation not covered by this AFI and immediate action is required. The aircraft commander is ultimate authority and is responsible for the course-of-action to be taken. Report deviations or exception without waiver through channels to MAJCOM Stan/Eval function who, in turn, should notify the OPR (lead command) for follow-on action, if necessary.
 - 1.4.1. Unless otherwise directed in this AFI, waiver authority for the contents of this document is the MAJCOM/DO. MAJCOM/DO staff should forward a copy of approved waivers to the OPR (lead command). Request for a long-term (permanent) waiver must be approved by MAJCOM/DO and listed in MAJCOM supplement (see paragraph 1.5.).

- 3.10.2.4 Initiate interfly approval request by the unit or agency requesting the agreement by memo or message format to the OG/CC controlling the resource. Each commander involving resources (personnel or aircraft) (or MAJCOM, if appropriate) must concur with interfly proposal. Request must include details of the deployment or mission including; aircrew name(s), duration, or special circumstances.
- 3.10.2.5. Flight Mishap accountability is MAJCOM designated PEID code for mishap aircraft.
- 3.10.2.6. Ground Mishap accountability in accordance with AFI 91-204, *Safety Investigations and Reports*.

Chapter 4

AIRCRAFT OPERATING RESTRICTIONS

- **4.1. Objective**. Redundant systems may allow crews to safely perform some missions when a component/system is degraded. The Aircraft Commander (AC) is the final authority in determining the overall suitability of an aircraft for the mission. The AC will ensure a detailed explanation of the discrepancy is entered in the AFTO Form 781A, **Maintenance Discrepancy and Work Document**; include the following maintenance identifiers to effectively communicate aircraft status:
- 4.1.1. Mission Essential (ME). The AC will designate an item, system, or subsystem component essential for safe aircraft operation as ME.
- 4.1.2. Mission Contributing (MC). The AC will designate an item, system, or subsystem component, which is not currently essential for safe aircraft operation as MC. These discrepancies should be cleared at the earliest opportunity. If circumstances change or mission safety would be compromised, re-designate as ME. Do not delay a mission to clear a MC discrepancy.
- 4.1.3. Open Item (OI). The AC will designate discrepancies not expected to adversely impact the current mission or any subsequent mission as an OI. These items are normally cleared at home station.
- **4.2. Minimum Equipment List (MEL) Policy**. The MEL is a pre-launch document that lists the minimum equipment/systems to operate the aircraft. It is impractical to prepare a list that would anticipate all possible combinations of equipment malfunctions and contingent circumstances. Consider equipment/systems with no listed exceptions as grounding items. An AC who accepted an aircraft with degraded equipment/systems is not committed to subsequent operations with the same degraded equipment. ACs are not committed to operations with degraded equipment accepted by another AC.
- 4.2.1. The AC shall account for the possibility of additional failures during continued operation with inoperative systems or components. The MEL is not intended for continued operation over an indefinite period with systems/subsystems inoperative.
- 4.2.2. All emergency equipment will be installed unless specifically exempted by mission requirements/directives.
- 4.2.3. Waiver Policy. An AC prepared to operate with a degraded MEL item shall request a waiver through C2 channels. The AC shall provide the C2 agent: 1) nature of request, 2) individual crew member qualification, 3) mission leg(s) requiring the waiver, and 4) the governing directive of waiver request to include volume, chapter, or paragraph. Initiate waiver requests as soon as possible; plan at least a 1-hour waiver process time.
- 4.2.4. ACs operating with waiver(s) for degraded equipment shall coordinate mission requirements (i.e., revised departure times, fuel requirements, maintenance requirements, etc.) with the controlling C2 agency.
- 4.2.5. If beyond C2 communication capability, or when it is necessary to protect the crew or aircraft from a situation not covered by this chapter and immediate action is

- required, the AC may deviate according to Paragraph 1.4. Report deviations (without waiver) through channels to MAJCOM/DO within 48-hours. OG/CCs shall collect background information and submit a follow-up written report upon request.
- **4.3. Waiver Protocol.** Waivers to operate with degraded equipment are granted on a case-by-case basis. The AC determines the need for a waiver after coordinating with the lowest practical level of command. MEL waiver authority is as follows:
- 4.3.1. Training Missions. OG/CC or equivalent with mission execution authority.
- 4.3.2. MAJCOM Directed Missions. MAJCOM/DO with mission execution authority for active duty, AFRC, or ANG units flying MAJCOM-directed missions (includes Operational Readiness Inspections). Initiate the request with MAJCOM C2 agency. For AMC-directed missions contact HQ AMC/DOV through TACC.
- 4.3.3. Contingency Missions. DIRMOBFOR (or equivalent) for the agency with C2, if not specified in the OPORD/Tasking Order.
- 4.3.4. ANG or AFRC Directed Missions. ANG or AFRC maintains C2 and waiver authority for ANG or AFRC directed mission prior to mobilization.
- 4.3.5. Other Than MEL Waivers. Determine governing source document (i.e. AFI, Flight Manual, Maintenance T.O., etc.) to ascertain the waiver authority. Use C2 channels to notify the appropriate waiver authority. Waivers of this nature may require an extended response time.
- **4.4. Technical Assistance.** The AC may request technical support and additional assistance from their home unit or MAJCOM C2 agency. See **FCB** for appropriate telephone numbers.
- **4.5. MEL Table Definitions/Column Identifiers.** MEL tables are arranged by aircraft system to provide the AC a mechanism to determine minimum system requirements. Components are listed by number installed and minimum required for flight. Requirements are defined by Home Station Mission Originator (Column A) and en route (Column B). Local training missions, to include off-station trainers, fall under Column B. An asterisk (*) in the Required column indicates the number required is situation dependent; refer to the Remarks/Limitations/Exceptions column for clarification.
- 4.5.1. Remarks/Limitations/Exceptions. Some technical information and procedures are contained in this column. This is not all-inclusive; crewmembers shall refer to the flight manual and other directives for procedures, techniques, limitations, etc.
- 4.5.2. One-time Flight Clarification: Normally a Red X discrepancy downgraded for a one-time flight without passengers. The LG/CC who owns the aircraft is the approval authority. Cargo may be carried as long as safety-of-flight is not compromised. The priority is to move the airplane to a repair capable facility; once repaired, the mission can be completed. ACs must coordinate with appropriate agencies to ensure repair capability exists at the destination. One-time flights may include en route stops only when necessary to recover the airplane. *Example*: An airplane departs on a gear-down flight from Djibouti IAP and requires an en route fuel stop (Cairo) before landing at the nearest repair capable facility, Sigonella AB.

- 4.5.3. One-time flight to nearest repair capable facility: Flight is limited to the nearest (shortest en route time) repair capable base.
- 4.5.4. One-time flight to a repair capable facility: Same as **4.5.3.** except the flight is not restricted to the nearest repair capable facility.
- 4.5.5. Other Mission and Repair Clarifications:
- 4.5.5.1. Shall be repaired at next repair capable facility: Mission may continue as scheduled; item shall be repaired upon reaching a repair capable facility. Designate item ME upon reaching repair facility. Once maintenance action is initiated, and it is determined repairs are not possible, the AC will discuss possible courses of action with command and control. Enroute repair capable facilities are deemed so regardless of parts availability. *Example:* If Yokota AB did not have the required part, the aircraft is not cleared to proceed without a waiver.
- 4.5.5.2. Repair as soon as practical: Item should be repaired when ground time permits. Do not delay the mission even if at a maintenance capable facility.
- 4.5.5.3. Mission may continue: Regardless of location, do not delay the mission, continue as scheduled. Item is designated MC; repair per paragraph **4.1.2.**
- 4.5.5.4. Mission dictates requirement: Consider entire mission not just the next leg. *Example:* An airplane is departing an en route station with maintenance capability, after engine start it is discovered that the #1 engine anti-ice is inoperative. Icing conditions are not forecasted for the next leg. However, because the mission spans several days and repair capability does not exist at the scheduled en route stops, the AC elects to have the item repaired prior to departing.
- **4.6. C-17 MEL.** This MEL applies to all C-17 models and lists the minimum equipment and systems to launch the aircraft under routine operations. The MEL does not include all equipment or systems essential to airworthiness. The MEL is not intended to promote continued operation of the aircraft for an indefinite period with systems/subsystems inoperative. See this chapter for further information including objectives, policy, and waiver protocol. Additional guidance specific to SOLL operations are listed in **Addenda B**, *C-17 Special Operations*.
- **4.7. Supplements.** Each MAJCOM may supplement the MEL (see Chapter 1).
- 4.8. Navigation Systems.
- 4.8.1. Equipment listed in FLIP for permitting compliance with MNPS is mandatory. Loss of any component before airspace entry requires return to a station with maintenance capability or re-filing via routes permitting equipment degradation.
- **4.9. Gear Down Flight Operations.** During peacetime, gear down flight operations will be limited to those sorties required to move the aircraft to a suitable repair facility. Gear down flight should only be considered and approved after all avenues to repair the aircraft have been exhausted. Each gear down sortie will be approved by the MAJCOM/DO.

Table 4.1. Air Conditioning/Pressurization

Item/System	Message/Cue/Alert	Installed	d Required		
_			A	В	Notes/Limitations/Exceptions
Air Conditioning Pack	L or R Pack "Disagree"	2	2	1	These requirements include the H2O Separator, Flow Control Valve, Turbine Bypass Valve, H2O Injector Nozzle, and Air Cycle Machine. All equipment will be operable on the same side as the operable pack if one pack is inop
Ram Air Ventilation Valve		1	0	0	Both packs will be operational if inop
Ram Air Doors For Air Conditioning Pack		2	1	1	These requirements cover Exhaust Ram Air Valve, Actuator, Linkages and cables. Inop Ram Air Inlet Door will be wired open
Pack Discharge Pneumatic Thermostat		2	1	1	Will be operational on operating pack
Pack Discharge Temperature Sensor		4	2	2	Will be operational on operating pack
L/R Pack DISAG Switch		2	1	1	Operable switch will correspond to operating pack
HI Flow On Switch		1	0	0	Avionics Cooling Override Switch will be operational if HI-Flow Switch is inop
Remote Temp Control Switch		1	0	0	Loadmaster Temp Control Selector will be operational if Remote Temp Controller Switch is inop
Inlet Air Temperature Sensor		6	3	3	One sensor per zone will be operational
Zone Temperature sensor		6	3	3	One sensor per zone will be operational
Environ Control Panel, Bleed/Supply/Compt Temp Indicator		8	0	0	
Cargo Compartment Recirculation Fan		1	1	0	Will be operable if one pack is inop
Environmental System Controller (ESC)		2	2	2	Enroute, if one ESC is inop, continue to a station with repair capability
Cargo Compartment Exhaust Fan		2	0	0	
Trim Air Regulator		2	1	1	These requirements cover the Trim Air Differential Pressure Sensor. Inop, valve will be locked closed. All associated equipment will be operational on same side as operational trim air regulator
Trim Air Check Valve		3	2	2	Center check valve may be inop
Flt Deck Overhead Panel Trim Air Switch		1	0	0	
Cargo Compt AC Supply Check Valve		4	2	2	One per side required, inop valve will be closed

Table 4.1. Air Conditioning/Pressurization (Cont)

	stem Message/Cue/Alert Installed Required		uired		
·	9		Α	В	Notes/Limitations/Exceptions
Air Conditioning Outlet Air Valve		13	0	0	
Avionics Cooling Fan		3	2	2	These requirements cover the Avionics Cooling Check Valve
Avionics Ground Cooling Inlet Filter Assembly		1	0	0	Will have filter installed for ground operation of avionics equipment
Avionics Cooling Differential Pressure Sensor		2	1	1	
Avionics Cooling Inflow Valve		1	0	0	
Ground Inlet Shutoff Valve		1	0	0	Will be manually closed for flight if inop
Avionics Cooling Heat Exchanger		1	0	0	Will have air conditioning pack operating for ground ops. Valve will be manually locked open if heat exchanger is inop
Avionics Cooling Equipment Air Shutoff valve Assembly		10	0	0	Valve required to be closed if corresponding avionics equipment is not installed
Ramp Temperature Sensor		1	0	0	
Environmental System- Fire Detection Control Panel		1	1	1	These requirements cover the Trim Air OFF/DIS Switchlight.
LM Station Temperature Control Panel		1	0	0	Remote Temp Control Switch on ESCP will be operational.
Environ Control Panel APU Air Switch		1	0	0*	Required if no air cart available for engine start
Cabin Pressure Outflow Valve		1	1	1	These requirements include the Outflow Valve Actuator.
Cabin Pressure Controller	AUTO PRESS INOP/SINGLE	2	1	1	These requirements include Cabin Pressure Sensor and Outflow Valve Motor. One complete cabin pressure system will be operational
Positive Pressure Relief Valve		3	2	2	These requirements include the Positive Pressure Relief Valve Filter Assembly.
Negative Pressure Relief Valve		3	2	2	
Cabin Pressure Indicator Unit		1	1	1	Two of three indicators in panel will be operational
Cabin Differential Pressure Sensor		1	1	1	

Table 4.1. Air Conditioning/Pressurization (Cont)

Item/System	Message/Cue/Alert	. ,		ired	
rtem/system	Wiessage/Cue/Alert	Instancu	1		N /E /E
			A	В	Notes/Limitations/Exceptions
10000 Ft Pressure		1	1	1	
Warning Aneroid					
Switch					
Cabin Pressure Gauge		1	1	0	If inop, comply with T.O. 1C-17A-1,
(crew entry door)					Section II warning
Cabin Differential		1	1	1	
Pressure Indicator					
(cockpit)					
Cabin Altitude Rate of		1	0	0	
Climb					
Cabin Altitude Indicator		1	1	1	
Cargo Floor Heat		1	0	0	
Ramp Floor		2	2	1	
Heater/Blower					
Temperature Control			Req	Req	Auto or manual control. Remote Temp
			1	1	Control Switch may be inop if LM
					Temp Control is operational

Table 4.2. Anti-Ice

Item/System	m/System Message/Cue/Alert Installed Required				
			A	В	Notes/Limitations/Exceptions
Wing Ice Protection System (Includes valves, cockpit switch, temp sensor)		2	2	0*	Will be operational for flights into known or forecast icing. Failed valve will be locked closed.
Engine Anti-Ice Systems (Includes valves, cockpit switches, temp sensors)		4	4	0*	Will be operational for flights into known or forecast icing. If icing is anticipated, manually open Shutoff Valve after associated engine has been started.
Low Temp Cowl Ice Protection Sensor		4	4	0*	Will be operational for flights into known or forecast icing.
Air Data Sensor Heating		31	31	0*	Will be operational for flights into known or forecast icing.
Windshield Ice Protection		2	2	0*	Will be operational for flights into known or forecast icing.
Window Defog Control Box		1	1	1	
Windshield Wipers		2	2	0*	Required for flight through rain.
Ice Detector Probe		1	1	0	Crew will monitor for ice if inop.

Table 4.3. Equipment and Furnishings

Item/System	Message/Cue/Alert	Installed	Required		
			A	В	Notes/Limitations/Exceptions
Lavatory		1	1	1	Continue mission (if practical) to a facility with repair capability. Can be inop with comfort pallet onboard.
Potable Water System		1	0	0	If inop, ensure adequate supply of water
Refrigerator		1	0	0	

Table 4.4. Communications

Item/System	Message/Cue/Alert	essage/Cue/Alert Installed Required			
			A	В	Notes/Limitations/Exceptions
Communications Control Unit (CCU)	CCU FAULT X	2	2	2	A one time flight with one inop to a station repair capability is authorized.
Comm/Nav Control Panel (CNC)		2	2	1	
Control, Intercommunications Set (ICS)		7	4	4	Pilot's, copilot's, forward and aft loadmaster's intercom control sets (2341CT) will be operational. The Aft loadmaster ICS will be operational for backing, CDS, and personnel airdrop.
Comm 1		1	1	1	
Comm 2 / UHF / VHF		3	3	2	
Public Address System		1	1	0	When carrying passengers, will be operational unless other means of communication is available
HF Radios		2	0	0	As mission dictates for airspace
SURECOMM		1	0	0	

Table 4.5. Fire Protection

Item/System	Message/Cue/Alert	Installed	Required		
·			A	В	Notes/Limitations/Exceptions
Fire Detection System, Engine		4	4	4	Either loop A or B for each engine will be operational.
APU Fire Detection Sys		1	1	0	Either loop A or B will be operational. If inop the APU may not be used.
Smoke Detector, Cargo Compartment	Does not pass test	14	6	6	Sensors 9, 10, 13 & 14 plus two others will be operable
Lavatory Smoke Detector	Does not pass test	1	0	0	
Crew Rest Smoke Detector	Does not pass test	1	0	0	
Avionics Smoke Detector	Does not pass test	2	1	1	
IRU Smoke Detector	Does not pass test	4	4	3	Must correspond to inop IRU
Fire Bottle, Engine	"Agent Low"	4	4	4	A one-time flight to a station with repair capability is authorized.
Fire Bottle, APU		1	1	0	If inop then APU may not be used.

4.6. Electrical

Item/System	Message/Cue/Alert	Installed	Required		
*	8		A	В	Notes/Limitations/Exceptions
Integrated Drive Generators (IDG)	"GEN/OFF" Switchlight Illuminated	4	3	3	With two inop, one time flight to a station with repair capability is approved.
AC X-TIE	Traininated	1	1	1	If inop, continue mission to a repair facility provided 4 IDG's and all AC bus ties are operational. If operating with 3 IDG's or any AC bus tie is failed, a one-time flight to a station with repair capability is authorized.
AC BUS TIE Relays		4	4	4	With one inop and all IDGs operational, a one time flight to a station with repair capability is authorized.
DC Cross Tie		1	1	1	
DC BUS TIE Relays		2	2	2	With one inop and transformer rectifiers operational, a one time flight to a station with repair capability is authorized.
Transformer Rectifiers		4	3	3	DC X-TIE and both DC Bus Ties will be operational.
AC Instrument BUS Transformers		2	1	1	Operational transformer will be installed on bus #3.
Emergency Power Generation					
Batteries		2	2	2	
Static Inverter		1	1	1	
Transfer Buses	AC XFER BUS	2	2	2	
Emergency Power Relays		2	2	2	
Battery Chargers	BATT NOT CHARGING	2	2	2	
Loadmaster Buses 1 and 4	LM 1, or 4 BUSES		Req	Req	
External Power		1	1	0	External power is required for Aeromedical Evacuation Mission.
60hz Power Supply System		1	1	0	Will be operational for Aeromedical Evacuation Missions

Table 4.7. OBIGGS

Item/System	Message/Cue/Alert	Installed	Required		
			A	В	Notes/Limitations/Exceptions
OBIGGS Systems		2	0		As required for mission tasking and tank inerting requirements.

Table 4.8. Flight Controls (Auto-Flight)

Item/System	Message/Cue/Alert	Installed	Requi	ired	
,			A	В	Notes/Limitations/Exceptions
Flight Control Computer	FCC X	4	4	4	With FCC 1 and 4 and both SCEFCs operational, and no Pitch, Yaw, Roll, or Pitch Trim Fail Op messages illuminated, a one time flight to a station with repair capability at or below FL 200 is authorized.
Spoiler Control/Electronic Flap Computer		2	2	2	With 1 inop and 4 FCCs operational, a one-time flight to a station with repair capability is authorized.
Electronic Flight Control Axis	"FAIL" Light	5	5	5	
Alpha Limiter System	ALPHA LIMIT INOP	1	1	1	
Stall Warning System	STALL WARNING INOP	1	1	1	If one channel is failed, continue mission to a station with repair capability.
Stick Shaker		2	2	2	
Warning System Terrain Avoidance Warning System	GPWS/GPWS FAIL TAWS/TAWS FAIL	2	1	1	If both inop, continue the mission to a station with repair capability. No low level contour flight is authorized.
Auto Throttles		1	0	0	Vol 3 crew duty limits apply
Axis Fail Operation Modes	Roll, Yaw, or Pitch Fail Op		Req	Req	Do not takeoff with any axis fail op condition
Surface Fail Operation Modes	elevator, rudder, or slat Fail Op		Req		With any single surface fail op condition, continue mission to a station with repair capability.
System Fail Operation Modes	ADC Fail Op		Req		Continue the mission to a station with repair capability.
SCEFC THRTL FAIL	SCEFC THRTL FAIL		Req		A one-time flight to a station with repair capability is authorized.
Aileron Trim Actuator		1	1	1	
Flap Actuator Cylinder		8	8	7	All are required for Full-Flap operations.
Transducer, Flap Position		4	4	4	
Indicator, Flap Position		1	0	0	MFD indication will be operational.
Indicator, Speed Brake		1	0	0	MFD indication will be operational.
Trim Indicators, Aileron, Rudder, Horizontal Stabilizer		1	0	0	MFD indication will be operational.
Spoiler Assy & Actuator Cylinder		8	7	7	Will be failed retracted. All will be operational for ALZ operations.
Switch, Control, Direct Lift (DLC)		2	1	1	

Table 4.8. Flight Controls (Auto-Flight) (Cont)

Item/System	Message/Cue/Alert		Required		
	Ŭ		A	В	Notes/Limitations/Exceptions
Slat Actuator		16	14	14	One actuator per wing may be inop.
TOGA Button	TOGA Button Fail	1	1	1	
Aileron Actuator, Ratio		1	1	1	
Changer					
Aileron Actuator		4	4	2	If inop, one time flight to a station with
Cylinder Assembly					repair capability is authorized.
Transducer, RVDT,		4	4	3	Four required for ALZ operations.
Stick, Roll					
Module, Integrated		2	2	2	With the upper IFCM inop, a one time
Flight Control (IFCM),					flight to a station with repair capability
Rudder					is authorized.
Rudder Actuator		4	2	2	One per surface may be inop. Four
Cylinder Assembly					required for ALZ operations.
Elevator Actuator, Ratio		1	1	1	
Changer					
Autothrottle Disengage		1	1	0	Required for A/R missions.
Switch		ļ	ļ. —		
Module, Integrated		4	4	4	
Flight Control (IFCM),					
Elevator		0			24
Cylinder Assembly,		8	6	6	Maximum of one failed cylinder per
Elevator		2	_	2	surface.
Transducer, Position,		2	2	2	One channel in one RVDT may be
RVDT, Pitch Control Valve.		2	2	2	inop.
Control Valve, Horizontal Stabilizer		2	2	2	
Horizontal Stab Pitch		2	2	2	
Trim Motor, Hydraulic			²	2	
Tandem Control Valve		4	4	4	
Air Refueling Mode	A/R MODE INOP	 	Req	Req	Continue to station with repair
All Keluching Wood	A/K MODE INOT		rcq	rcq	capability if no A/R planned.
		l			capadinty if no A/K planned.

Table 4.9. Fuel

Item/System	Message/Cue/Alert	Installed	Required		
			A	В	Notes/Limitations/Exceptions
Valve Assembly, Solenoid, Fuel Vent, Override		2	0	0	Primary and secondary climb/dive valve will be operational.
Valve Assy, Secondary Climb/Dive		2	0	0	Primary climb/dive valve and override solenoid valve will be operational.
Valve Assy, Primary Climb/Dive		2	0	0	Secondary climb/dive valve and override solenoid valve will be operational.
Transfer Pumps		4	2	2	If fuel quantity in tank 2 or 3 is greater than 36K lbs, respective XFER pump will be operational. One transfer pump/switch per wing may be inop; tank with inop pump will have both boost pumps and crossfeed valve operational.

Table 4.9. Fuel (Cont)

Item/System	Message/Cue/Alert	Installed	Requ	uired	
·			Α	В	Notes/Limitations/Exceptions
Dump Valves		2	2	1	Left and Right Master, or Center
1					separation valve, will be operational.
Boost Pumps		8	6	6	One per wing may be inop if inboard
•					transfer pumps and crossfeed valves
					are operational on affected side.
Separation Valve		1	0	0	If failed closed, both A/R isolation
-					valves will be operable.
Receptacle, Ground		2	1	1	
Refueling					
Panel, Control, Ground		1	1	0	
Refueling					
Valve, Isolation, Ground		2	0	0	Inop valve will be closed manually
Refueling					prior to takeoff
Fill Valve		4	4	2	Four required for A/R missions. Fill
					valves 1 and 4 will be operational.
					Over wing refueling is required for
					affected tanks.
Hi-Level Shutoff Test		4	4	0	Four required for A/R missions.
Valve					Quantity Select method required for
					ground refueling.
Ground Refuel Switch,		2	0	0	Ground Refuel Panel will be
Overhead Panel		ļ	<u> </u>		operational
Crossfeed Valves		4	4	4	
Fuel Manifold Drain &		1	1	0	May be inop but manifold must stay
Check Valves & Pump			<u> </u>		dry and have manifold drain capability
Valve, Drain, Manual,		1	1	1	
Ground Refueling			!		
Low-Level Fuel Dump		4	4	4	
Shutoff		1	ļ	-	Will 1 1: C A: 1.
Fuel Quantity Computer		1	1	1	With one channel inop, one-time flight
					to a station with repair capability is
F1 Otit. Disulan		4	4	- 2	authorized.
Fuel Quantity Display,		4	4	3	Total fuel quantity indication will be
Overhead Panel Total Fuel Ouantity		1	1	0	operational. Required if any fuel quantity display
Total Fuel Quantity Indicator		1	1	U	inop.
UARRSI System		1	1	0	
•		1	0	0	Required for A/R missions. Door will be verified open before flight
Door Assembly & Handle, UARRSI		1	U	U	for AR missions.
Air Refuel Master		2	1	0	Inop valve will be manually closed
Valves		<u></u>	1	U	prior to takeoff. With any inop valve,
v a1 v C5					the center separation valve will be
					operable. One required for A/R
					missions.
Dimming Unit, A/R		1	1	0	Required for night A/R missions.
Annunciator		1	1		required for ingile twice imposions.
Annunciator Lights,		1	1	0	For A/R missions READY light may
READY, DISC. &		1	1		be inop if overhead panel READY
LATCHED, Center Post					light is operational.
- , - , - , - , - , - , - , - , - , - ,					
			1		<u> </u>

Table 4.9. Fuel (Cont)

Item/System	Message/Cue/Alert	Installed	Required		
			A	В	Notes/Limitations/Exceptions
Rheostat, Air Refuel		1	1	0	Required for night A/R missions.
Ann/Slipway, Overhead					
Panel					
Switch, L/R Master,		2	1	0	Separation valve will be operable.
DISAG, Air Refuel,					Inop valves will be closed prior to
Overhead Panel					takeoff. Required for A/R missions.
Switch, A/R Amp		1	0	0	Required if Override Boom Latching
Override, Overhead					authorized by mission directive
Panel					

Table 4.10. Hydraulics

Item/System	Message/Cue/Alert	Installed	Required		
	· ·		A	В	Notes/Limitations/Exceptions
Engine Driven Hyd Pumps		8	8	6	Only one pump per system may be inop. One pump on systems #2 and #3 may be inop provided the AUX pump for affected system and transfer pump are operational. If a pump fails to depressurize, a one time flight to a station with repair capability is authorized.
Aux Pumps		4	4	3	If the failed pump is on #2 or #3 system the transfer pump will be operational. If failed pump is on #1 or #4, a one time flight to a station with repair capability is authorized.
Transfer Pump		1	1	0	If inop, all system 2 and 3 (engine driven and AUX) pumps will be operational
Hydraulic Panels	HYD PANEL SINGLE/INOP	2	2	1	Continue mission to a station with repair capability
Hydraulic System Controllers	HCU SINGLE/INOP	2	2	2	
Hyd Manifold Press Transducer		4	3	3	Associated pump low pressure light and temp indicator required
Hyd quantity transducer		4	0	0	Associated system reservoir low quantity prox sensor required
Hyd low quantity prox sensor		4	0	0	Associated system reservoir hydraulic quantity transducer required
Ram Air Turbine		1	1	1	Will be stowed prior to departure

Table 4.11. Indicating Systems

Item/System	Message/Cue/Alert	Installed	Req	uired	
			A	В	Notes/Limitations/Exceptions
Proximity Sensor	PROX UNIT 1,2	2	2	2	
Interface Unit (PSDAU,					
PIU)					
Computer, Central Aural		1	1	1	
Warning					
Loudspeaker, CAWS		2	1	1	
Computer, Warning and		2	2	2	
Caution - WCC					
Annunciator, Lighted,		2	0	0	
WACS Fail					
Switch, Master Warning		2	1	1	
& Reset					
Switch, Master Caution		2	1	1	
& Reset					
ELT		1	1	1	
Underwater Beacon		1	1	0	
Cockpit Voice Recorder		1	1	1	If inop, a one time flight to a station
					with repair capability is authorized.
Single Flight Data		1	1	1	If inop, a one time flight to a station
Recorder					with repair capability is authorized.

Table 4.12. Landing Gear and Brakes

Item/System	Message/Cue/Alert	Installed	Requ	iired	
			A	В	Notes/Limitations/Exceptions
Wheel & Tire Assy,		12	12	12	
Main Gear					
Multiple Disk Brakes		12	10	10	
Brake Accumulator		2	2	2	
Control Unit, Antiskid-		1	1	1	
Brake Temp Monitor					
Transducer, Motional		12	10	10	Brakes (7 or 8) and (11 or 12)
Pickup, Wheel Speed, MLG					transducers will be operational. Brake on affected wheel will be capped.
Sensor, Temperature,		12	8	8	One sensor per bogie may be inop.
Brake Monitor					
Indicator, Brake		1	1	1	
Pressure, Cockpit					
Steering Cylinder		2	2	2	
Assembly					

Table 4.12. Landing Gear and Brakes (Cont)

Item/System	Message/Cue/Alert	Installed	Requi	ired	
			A	В	Notes/Limitations/Exceptions
Nosewheel Steering Control (Tiller)		2	2	2	With one inop, a one time flight to a station with repair capability is authorized. (The operable tiller will be in Pilot Flying position.)
Landing Gear Indicators		2	2	2	Accurate gear indication will be available on either CFG page or landing gear control indication panel. With one inop continue mission to a station with repair capability
Parking Brake	PARK BRAKE INOP	2	1	1	A one-time flight to a station with repair capability is authorized.

Table 4.13. Lighting

Item/System	Message/Cue/Alert	Installed	Requ	ired	
			A	В	Notes/Limitations/Exceptions
Flight Compartment Lighting		1	1	1	Main inst panel floodlight, cockpit dome and thunderstorm lights will be operational for night flight.
Light and Buttons, Nurse Call		2	0	0	Will be operable for Aeromedical Evacuation missions
Cargo Compartment Lighting			req	req	Adequate lighting to perform mission.
Light, Landing and Taxi, Wingtip		2	1*	1	One wingtip or nose landing light on each side will be operational.
Nose Landing Light		2	1*	1	One wingtip or nose landing light on each side will be operational.
Nose Taxi Light		2	1	1	One may be inop provided the nose landing light on the same side is operational. Not required if mission conducted during daylight hours.
Wingtip Navigation Light, Fwd Position		2	2	2	One bulb per wing will be operational. (Note: there are 2 bulbs in each lighting assembly.)
Wingtip Navigation Light, Aft Position		4	2	2	One position light assembly per wing will be operational. (Note: there are 2 light assemblies with single white bulbs on each wing.)
Upper & Lower Anti- Collision, Beacon		2	2	2	See AFI 11-202 Vol 3 for requirements. For SPRO ops, lower light may be removed.
Tailcone In-Trail Light		2	0	0	One required for night formation flight.
Wing In-Trail Light		2	0	0	Two required for night formation flight. Wing tip position lights can be used as an alternate for training only.
Fuselage In-Trail Light		2	0	0	Two required for night formation flight.

Table 4.13. Lighting (Cont)

Item/System	Message/Cue/Alert	Installed	Requi	ired	
			A	В	Notes/Limitations/Exceptions
A/R Flood and Spot Light		1	1	0	Required for night A/R.
UARRSI Perimeter Light Panel		3	3	0	Required for night A/R.
Emergency Exit Sign/Light		13	13	13	
Emergency Lighting, Battery Power Supply		3	3	3	
Wing Tip (Strobe) Recognition Lights		4	0	0	See AFI 11-202 Vol 3 for requirements

Table 4.14. Navigation Systems

Item/System	Message/Cue/Alert	Installed	Requ	ired	
			A	В	Notes/Limitations/Exceptions
Pitot Static Probes	P/S XX MAST/HEAD HTR	4	3	3	Upper left (1A) and lower right (2A) probes will be operational to provide standby pitot static instruments
Standby Attitude Indicator		2	2	1	Pilot will have a full set of standby indicators.
Standby Altimeter Airspeed Indicator		2	2	1	Pilot will have a full set of standby indicators. Altimeter set function will be operational on both.
BDHI		2	2	1	Pilot will have a full set of standby indicators.
Air Data Computer Channels		4	4	3	With ADC1A inop, a one-time flight to a station with repair capability is authorized.
IRUs		4	4	3	Includes IRU batteries. See FCC inop guidance.
GPS		2	2	0	As required for ATC airspace restrictions
TACAN		1	1	0	As required for mission accomplishment
PLSR 1/2		2	2	2	
DME 1/2		2	1	1	As required for mission accomplishment
LF/ADF		1	0	0	As required for mission accomplishment
RADAR Altimeter		2	1	1	•
Weather RADAR		1	1	0	Required for air refueling and when thunderstorms are forecast for the planned route of flight
IFF/TCAS		1	1	1	Mode 1, 2, 4, & TCAS may be inop based on msn/airspace requirements.

Table 4.14. Navigation Systems (Cont)

Item/System	Message/Cue/Alert	Installed	Requ	ired	
			A	В	Notes/Limitations/Exceptions
CIP		2	2	2	
SKE		1	0	0	As required for mission accomplishment
MCD		4	4	3	
Data Entry Keyboard (MCK)		2	2	2	
HUD		2	2	1	5 of 6 displays (HUD/MFDs) will be operational. 2 req'd for ALZ/NVG.
MFD		4	4	3	5 of 6 displays (HUD/MFDs) will be operational.
MFC		2	2	2	
A/PDMC		2	2	1	

Table 4.15. Oxygen

Item/System	Message/Cue/Alert	Installed	Requ	ired	
			A	В	Notes/Limitations/Exceptions
25 liter Crew LOX Converter	CREW OXY LOW	1	1	1	May be inop if PAX and/or auxiliary system and crossfeed are operational.
75 liter PAX LOX Converter	OXY LOW	1	1	1	May be inop if auxiliary system is operational.
75 liter AUX Converter	OXY LOW	1	1	1	May be inop if passenger system is operational.
Regulators		10	3	3	Pilot, co-pilot, loadmaster regulators will be operational. Other regulator(s) required for each occupied crewmember position.
Portable Oxygen Bottles		9 (10)	9 (10)	6	Two minimum required for each primary crewmember. Ensure requirements of AFI 11-202 Vol 3, Table 6.1, are met. (10 bottles w/TCTO 762)
Quick Don Mask		15	15	3	Required for each primary crewmember. Ensure requirements of AFI 11-202 Vol 3, Table 6.1, are met.

Table 4.16. Bleed Air

Message/Cue/ Alert	Installed	Requ	ired	
		A	В	Notes/Limitations/Exceptions
	4	2	2*	One SOV per wing may be inop provided flight is not conducted into known or forecast icing conditions. All components will be functioning on the operational bleed systems
	1	1	1	May be manually closed after engine start. If manually closed, two bleed sources required for each operating pack.
	2	0	0	APU required if ground service connector inop.
	142	71	71	One loop will be operable per region
	4	2	2	One per wing will be operable.
	8	4	4	One per engine will be operable
	Message/Cue/ Alert	2 142 4 8	1 1 2 0 142 71 4 2 8 4	4 2 2* 1 1 1 2 0 0 142 71 71 4 2 2 8 4 4

Table 4.17. Cargo Mission Systems (Airland)

Item/System	Message/Cue/Alert	Installed	Requ	ired	
			A	В	Notes/Limitations/Exceptions
Ramp Toes		4	4	0*	Will have both stowage pins in each toe. At least one of the ramp toes requires an operational proximity sensor. May have less than 4 operational toes if not needed for mission accomplishment.
Cargo Loading Stabilizer Struts		2	2	0*	Required to jack the aircraft. Mission may continue if struts are not needed for mission accomplishment. Continue to a station with repair capability.
Cargo Rail and Locks (ADS and Logistic)					As required for mission accomplishment.

Table 4.17. Cargo Mission Systems (Airland) (Cont)

Item/System	Message/Cue/Alert	Installed	Required		
			A	В	Notes/Limitations/Exceptions
Cargo Winch		1	1		Mission may continue if winch is not needed for mission accomplishment.
Aircrew Data Transfer Device		1	1	0	

Table 4.18. Cargo Mission Systems (Airdrop)

Item/System	Message/Cue/Alert	Installed	Required		
			A	В	Notes/Limitations/Exceptions
TRM		1	1	0	Required for equipment airdrop
Rail Bridge Assembly		1	1	0	Required for equipment airdrop
Ramp Edge Covers		1	1	0	Required for equipment airdrop
Retrieval Winches		2	2	0	As required for CDS or personnel airdrop
GRM		6	6	0	As required for CDS airdrop
BSA		1	1	0	Required when dropping CDS > 9400 lbs.
Canadian Retrieval System		2	2	0	As required for personnel airdrop
Paratroop Doors		2	2	0	As required for personnel airdrop
Air Deflector Doors/Pod		2	2	0	As required for personnel airdrop
Fairings					
ADSC		1	1	1	All associated components for airdrop are required.

Table 4.19. Doors

Item/System	Message/Cue/Alert	Installed	Required		
			A	В	Notes/Limitations/Exceptions
Crew Entrance Door	"ENTRY DOOR"	1	1	1	Indicating systems will be operational.
Emergency Exit	"EMERG EXIT"	1	1	1	
Crew Entry, Emergency Exit, Hor/Vert Stab Access, Crew Oxygen, Belly Maintenance Door Proximity Indicating Systems					May be inop if the door is visually verified closed and locked.
Cargo Ramp Latches/Locks		22/2	22/2	22/2	All cargo ramp latches and electrical safety locks will be operational. Manual operation permissible, unless aeromed or airdrop.

Table 4.19. Doors (Cont)

Table 4.19. Doors (Cont Item/System	Message/Cue/Alert	Installed	Required		
item system		Instanca	A	В	Notes/Limitations/Exceptions
Cargo Door/Ramp Proximity Indicating Systems					All proximity sensors and indicating systems affecting the ADSC, LFCP, LACP, and PADS will be operational for airdrop missions. All proximity sensors and indicating systems associated with the cargo door system will be operational. May be inop on unpressurized flights if it can be determined that the locks are positively locked. But, with palletized cargo on board, all door/ramp locks are required to permit cargo jettison.
Cargo Door Downlock Assemblies		2	2	2	required to permit emge jeunem
Sidewall Jamb Spindles		34	34	34	
Cargo Door Ditching Locks		4	4	4	Cargo door, ramp, and ditching locks will be operational (without the use of manual override). Manual override procedures may be used to continue the mission to a repair facility. Cargo door, ramp, and ditching locks will be operational (without the use of manual override) for all missions that require in-flight use of cargo door and ramp.
Cargo Door Uplocks		2	2	2	
Cargo Ramp		1	1	1	All cargo ramp latches and electrical safety locks will be operational.
Paratroop Doors		2	2	0	As required for mission accomplishment
Air Deflector Doors/Pod Fairings		2	2	0	As required for mission accomplishment

Table 4.20. Engines/APU

Item/System	Message/Cue/Alert	Installed	Required		
	· ·		A	В	Notes/Limitations/Exceptions
Engines		4	4	4	
EEC	EEC FAULT X	4	4	4	One channel (A or B) may be inop. If channel A is inop, engine will operate in N1 mode.
Ignition System		8	8	4	One ignition source per engine may be inop. Only 1 engine may have CH A inop—one time flight to a station with repair capability is approved.
TCA Valve	ENG STABILITY X	4	0	0	Valve will be locked open if inop.
EGT Thermocouple Probes		24	20	20	6 probes per engine, 5 required; 2 channels per engine, 1 required.
SED		1	1	1	
Thrust Reversers		4	2	0*	Inop TRs will be locked out in symmetrical pairs.
Oil Quantity Transmitter	ENG OIL ABNORMAL	4	0	0	Oil pressure and temp indications will be operational. Verify oil quantity prior to flight.
Low Oil Pressure Switch	ENG OIL PRESSURE	4	4	4	Monitor oil pressure on MFD.
Starter Control Valve		4	4	4	Starter control valve will be operable manually. For manual operation, starter position indicator must be operable.
APU		1	1	0	APU will be operational for any mission departure into a field without alternate electric/air sources when engine shutdown is planned.

Table 4.21. Emergency Equipment

Item/System	Message/Cue/Alert	Installed	Required		
			A	В	Notes/Limitations/Exceptions
FEDS Life Rafts (includes Retractor Assembly and Ladders)		3	3	0	Raft quantity will be adequate to accommodate total persons onboard (46 per raft) when flight exceeds power off gliding distance from land.
FEDS Initiators		7	7	6	All required for flights exceeding power off gliding distance from land. Exterior initiator is required at all times.
Fire Extinguishers		9	9	9	
Crash Axes		2	2	2	
Ramp Blow Down System		1	1	0	Required for Aeromedical Evacuation Missions

Chapter 5

OPERATIONAL PROCEDURES

- **5.1.** Checklists. A checklist is not complete until all items have been accomplished. Momentary hesitations for coordination items, ATC interruptions, and deviations specified in the flight manual, etc., are authorized. Notes amplifying checklist procedures or limitations may be added to the checklists (in pencil).
 - 5.1.1. Checklist Inserts. Units may supplement T.O. guidance with HQ AMC/DOV approved checklist inserts. These inserts may be placed at the end of the appropriate checklist or in an in-flight guide. All checklist inserts must have a POC.
 - 5.1.2. If any crew member has recommendations or change to the Checklist Instert, contact the POC. The POC will consolidate inputs and submit changes to HQ AMC/DOV for approval. Local in-flight guides and inserts not affecting T.O. guidance and procedures may be locally developed and OGV approved.
- **5.2. Duty Station.** A qualified pilot will be in control of the aircraft at all times during flight. **EXCEPTION**: Unqualified pilots undergoing qualification training and senior staff members who have completed the ATS Senior Officer Course under the direct supervision of an instructor pilot. The aircraft commander, copilot, and loadmaster will be at their duty stations during critical phases of flight:
 - 5.2.1. During other phases of flight, crew members may leave their duty station for brief periods to meet physiological needs and to perform normal crew duties. Only one pilot may be absent from their duty station at a time. Notify the aircraft commander before departing assigned primary duty station. **EXCEPTION**: On augmented AR missions when two or more air refuelings are scheduled and the crew contains more than one air refueling qualified aircraft commander, an aircraft commander (not necessarily the "A" coded aircraft commander on the flight orders) must be in the seat during refueling operations.
- **5.3. Flight Station Entry.** Aircraft commanders may authorize passengers and observers access to the flight station during any phase of flight. In all cases, sufficient oxygen sources must be available to meet the requirements of AFI 11-202V3. Passengers and observers will not be permitted access to primary crew duty station regardless of its availability.
- **5.4. Takeoff and Landing Policy.** After thoroughly evaluating all conditions, the aircraft commander will determine who accomplishes the takeoff and landing and occupy either the left or the right seat during all takeoffs and landings.
 - 5.4.1. A qualified aircraft commander will accomplish all approaches and landings under actual emergency conditions unless specific conditions dictate otherwise.
 - 5.4.2. Aircraft commanders who possess less than 100 hours in command since certification in the C-17 will perform all takeoffs and landings from the left seat.

EXCEPTION: They may allow aircraft commanders (with more than 100 hours in command), or higher to perform takeoffs and landings when required for currency.

Chapter 24

NIGHT VISION GOGGLE OPERATIONS (NVG)

- **24.1. General.** This chapter provides guidance for C-17 NVG operations. It is applicable to all C-17s required to perform missions employing NVGs. Where not specifically stated in this chapter, all operational restrictions for operations are identical to those contained in the other chapters of AFI 11-2C-17V3. AFI 11-2C-17V3, Addenda B provides guidance for SOLL II operations and training; where not specifically stated in that addenda, all operational restrictions for operations are identical to those contained in this and the other chapters of AFI 11-2C-17V3. NVGs are a tool for enhancing situational awareness in the low-light environment. Crewmembers should use all means available (autopilot, flight instruments, navigational systems) to maintain situational awareness. Because NVGs do not turn "night into day," crewmembers must be aware of the limitations of NVGs.
- **24.2. Training/Operations.** Accomplish aircrew training according to AFI 11-2C-17V1 and MAJCOM approved training guides before NVG use. SOLL II crews will complete basic NVG training (including airdrop) in addition to SOLL II training. SOLL II crews will only use SOLL procedures on designated SOLL missions with SOLL-trained crews.
- 24.2.1. Pilots shall only perform NVG approaches on training missions and operational missions when the OPORD, mission directive or tactical situation dictates.
- 24.2.2. Pilots may use NVGs even if the loadmaster on the crew is not NVG certified, provided no NVG ground operations are planned/required. During contingency operations, all crew members should be NVG qualified.
- 24.2.2. Air Refueling. Pilots may use NVGs during air refueling rendezvous to acquire the tanker but must remove goggles NLT one nautical mile from the tanker.
- 24.2.3. Touch-and-Go landings on NVGs are authorized IAW Chapter 9 of this regulation.
- **24.3. Mission Planning.** Pilots require one full day of planning for any missions employing NVGs in the low-level environment. Route selection and mission planning techniques and procedures should incorporate strategies for enroute climbs and descents to optimize night terrain usage for threat avoidance. A leg segment should not be less than 10 NMs in length to minimize unnecessary altitude changes.
- **24.4. Weather Minimums**. Use of NVGs in IMC is prohibited. Other weather limitations are IAW this instruction and AFI 11-202V3. NVGs have inherent limitations which can further be reduced by poor weather conditions. Crews will consider weather conditions, moon illumination and position, sky glow at dawn and dusk, cultural lighting, and weapon/expendable effects when planning NVG operations.
- 24.4.1 Wind Limitations. When using NVGs for landing, the maximum allowable crosswind component is 30 knots, however OG/CC (or equivalent) approval is required to exceed 20 knots.
- **24.5. Minimum Operational Equipment.** The following equipment is required for NVG operations (in addition to Chapter 4):

- 24.5.1. NVGs that are HUD compatible (F4949G or L) mounted on a standard aircrew helmet. One spare set of NVGs per crew. Each crewmember will carry approved spare batteries for their own NVGs. All crewmembers will preflight their own NVGs prior to flight. The spare will also be preflighted.
- 24.5.2. For missions that will require takeoff/landing on NVGs, the two wingtip landing lights will have infrared (IR) filters installed. Both will be operational for launch. If, after departure, one of the IR filtered landing lights fails, the mission may be made continued at the AC's discretion. Consideration should be given to using the overt taxi lights if the runway/ALZ can be lit normally (threat permitting). Divert to an alternate location if landing with one IR landing light isn't feasible.
- 24.5.3. An operational HUD is required in both pilot positions to conduct NVG operations.
- 24.5.4. One radar altimeter.
- 24.5.5. Cargo compartment red lights or MAJCOM-approved NVG lighting.
- 24.5.6. Each pilot will carry a NVG-compatible flashlight, personal lip/finger light (as desired), and/or Chem lights.
- **24.6. Aircraft Preparation.** In addition to the normal aircraft preflight, crewmembers may have specific tasks to prepare the aircraft for NVG missions. Additional equipment may be necessary to prepare the aircraft and crewmembers for missions that utilize NVG operations.
- 24.6.1. Aircraft Kit.
- 24.6.1.1. IR filters for landing lights (mandatory on all NVG missions).
- 24.6.1.2. Porthole covers. (Blacked out requirement only)
- 24.6.1.3. Tape. (Blacked out requirement only)

24.7. Aircraft Lighting

- 24.7.1. During combat/contingency operations, the tactical situation may dictate the use of all, some, or none of the aircraft exterior lights as determined by the mission commander. Lights-out operations during peacetime will be conducted in warning or restricted areas IAW AFI 11-202V3 unless a letter of agreement exists with the FAA. Use the following guidance for aircraft exterior lighting configurations when operating outside of these areas.
- 24.7.1.1. Navigation Lights: Steady, bright.
- 24.7.1.2. Formation Lights: On, medium (formation operations only).
- **WARNING:** Immediately discontinue use of NVGs, and/or increase spacing from preceding aircraft (if possible), when exterior lights in a preceding aircraft create excessive distractions or degrade performance of NVGs to the point where safe flying operations cannot be maintained.
- 24.7.1.3. Anti-Collision: On, lower (upper and lower for single ship operations or for the last aircraft in the formation unless it causes distractions).

24.7.1.4. Landing lights. IR landing lights will be turned on no later than 400' AGL on final.

24.8. NVG Donning/Doffing Procedures.

24.8.1. Donning and doffing of NVGs will be initiated by the aircraft commander through the use of the Combat Entry/Exit Checklist or as briefed. If in formation, donning and doffing times will be determined in the formation briefing. For non-NVG landings, cease NVG usage 5 minutes prior to landing to regain adequate night visual acuity. Normally, NVGs will be doffed during the Combat Exit Checklist.

24.9. NVG Enroute Procedures.

- 24.9.1. Inadvertent Weather Penetration Procedures. Undetected meteorological conditions represent one of the most dangerous conditions facing a crew using NVGs. The onset of 'scintillation', a loss of scene detail, or a change in the appearance of halos represent three of the best clues to the possibility of inadvertent weather penetration. If IMC conditions are encountered, crews will cease NVG use until VMC conditions can be attained. If appropriate, execute Inadvertent Weather Penetration Procedures IAW Chapter 18 of this instruction.
- **24.10. NVG Airland.** Use of NVGs for airland operations is a tactical event. See Chapter 3 of this regulation for restrictions. NVG airland pilots are authorized to takeoff and land on runways meeting the requirements in Chapter 5.
- **NOTE 1:** NVG airdrop pilots that are not NVG airland qualified may use NVGs for ALZ/airfield acquisition. The pilot flying the approach and landing will remove NVGs no later than 5 minutes prior to landing. The PNF will remove NVGs as soon as the ALZ is acquired but no later than glideslope intercept.
- **NOTE 2:** ALZ lighting patterns will be IAW AFI 13-217. The AC must ensure landing TOLD data reflects the possibility for a landing at the end of the zone (subtract landing/safety zone distances from runway available to ensure adequate runway exists for rollout).
- 24.10.1. Radar Marker. The radar markers should remain set at enroute altitude setting IAW the Combat Entry Checklist until the slowdown for airland maneuver. Once the Approach Checklist is initiated, the radar altimeter may be reset to assist in landing.
- 24.10.2. NVG Approaches and Landings.
- 24.10.2.1. Visual Approaches. Since the primary threat avoidance tactic employed by landing on NVGs is making the aircraft hard to see, arrival tactics will involve less aggressive maneuvering for a given threat than would be accomplished during the day or "lit up" at night. NVG visual approaches will be flown to no less than a 1.5 mile final, and intercept target approach path angle at no lower than 500 AGL. Consider aircraft weight and its effect on the approach. The first pilot to acquire the landing zone will state "Pilot/Copilot has the LZ". The next pilot to acquire the zone will announce "Pilot/Copilot has the LZ at (state clock position)". Use automation as appropriate to reduce pilot workload.

- 24.10.2.2. Instrument Approaches. Use of NVGs is permitted during instrument approaches flown in VFR conditions.
- 24.10.2.3. Assault landings. Assault landings on NVGs are prohibited. Assault landing procedures are required when the mission computer TOLD derives a ground roll versus a landing distance. Full flap landings using TOLD where landing distance is generated in the mission computer require thorough understanding of TOLD assumptions (TCH, braking, and thrust reverser use).
- 24.10.3. Go-Around and Departure Procedures. Whether maneuvering for another approach or proceeding with the mission, fly as high as operational requirements allow, and no lower than enroute or pattern altitude.
- **CAUTION:** Pilots are especially susceptible to spatial disorientation during NVG goarounds and departures.
- 24.10.4. Ground Operations.
- 24.10.4.1. Lighting. Operating landing/taxi lights with IR filters for more than 5 minutes on the ground will cause damage to the lights/filters.
- 24.10.4.2. ERO. Reduced light EROs must be accomplished with red (overt) lighting in the cargo compartment sufficient to permit MHE drivers to see mashaller's signals and safely position MHE and maneuver the load behind the aircraft without use of NVGs. (Dimming rheostat set no lower than nine to ten o'clock). LMs may use NVGs to maintain situational awareness of the load team behind the aircraft before or after actual loading.
- 24.10.4.3. Taxi/backing. Pilots may taxi using NVGs on airfields without lights (blacked out) or equipped with overt or covert lights. If taxiing or accomplishing ground ops on blacked out taxiways/runways/ramps, the Aircraft Commander will ensure aircraft or environmental lighting provides for clear definition of taxiway/runway/ramp edge. Comply with all taxi restrictions in Chapter 5 and the Airfield Suitability and Restrictions Report. The LM may provide the pilot with directions to taxi the aircraft while using NVGs.
- 24.10.4.4. Combat Offloads. Pilots and LMs may accomplish Combat Offloads on NVGs at light levels up to and including blacked out provided aircraft or airfield lighting permit clear definition of taxiway/runway/ramp edges.
- **24.11. NVG Airdrop Procedures.** Qualified NVG airdrop pilots are authorized to perform normal night operations (including low level flying and formation) at night VMC altitudes IAW Chapters 18 and 19 of this regulation. Airdrops may be accomplished on drop zones lit IAW AFI 13-217 lighting patterns (covert and overt) while wearing NVGs, to include unmarked drop zones. Mission requirements will dictate the release method used.
- 24.11.1. Loadmasters will use NVGs during airdrops if the mission dictates. Loadmasters are authorized to perform heavy equipment and container delivery system airdrops with minimum lighting. Use NVGs as necessary to assist with operations and keep cargo area lighting to a minimum. During static line personnel operations, use of

NVGs in the cargo compartment is not authorized; however, use of NVGs on the flight deck is authorized.

- 24.11.2. Checklist Usage. Follow checklists and procedures in Chapter 19 of this AFI.
- 24.11.3. Cargo Compartment Lighting. After the Combat Entry Checklist, all cargo compartment lighting will be switched to red lights. Blacked out (no-light) operations in the cargo compartment are not authorized. Adjust red light intensity to between the nine and ten o'clock position. Loadmasters will carefully consider cargo compartment lighting intensity prior to opening ramp and door to minimize interference with formation wingmen's NVG vision.

24.12. NVG Formation Procedures.

- 24.12.1. Rejoin Procedures. NVG formation rejoins will be IAW **Chapter 18** of this AFI. Formation rejoin altitude will be no lower than MSA. Coordinate for exterior lighting and/or SKE procedures as required.
- 24.12.2. Landing. Obtain spacing for landing prior to descending from enroute altitude.
- **24.13. NVG Emergency Procedures.** Crews will review and coordinate NVG failure procedures for all phases of the mission. The PNF will be ready to immediately assume aircraft control if the PF experiences spatial disorientation or an NVG malfunction. During cargo compartment emergencies, return to normal lighting until the emergency is resolved. Discuss actions for Smoke and Fumes in the aircraft.
- 24.13.1. Enroute Flight through Completion of Slowdown.
- 24.13.1.1. Single-ship or formation lead. For enroute operations, if either pilot's NVGs become inoperative, transfer aircraft control to the other pilot, and transition to a spare set. If the difficulty cannot be corrected, terminate NVG operations.
- 24.13.1.2. Formation wingmen. Maintain formation position if able. Transfer aircraft control and transition to a spare set of NVGs. Maintain enroute spacing from other aircraft in the formation until the problem is resolved and continued safe low-level operations can be ensured. If the difficulty cannot be corrected, terminate NVG operations, notify lead and exit the formation.
- 24.13.2. Slowdown through Escape.
- 24.13.2.1. Single-ship and formation lead. If either pilot's NVGs become inoperative, continuing the airdrop will be at the aircraft commander's discretion. As a guide, if the DZ is in sight and CARP alignment has been confirmed between the PF and the PNF, the airdrop may be continued.
- 24.13.2.2. Formation wingmen. Maintain formation position if able. Notify lead when appropriate. Transfer aircraft control if appropriate and transition to a spare set. Maintain drop spacing from other aircraft in the formation until the problem is resolved and continued safe airdrop operations can be ensured. If the difficulty cannot be corrected, terminate NVG operations, exit the formation and execute a no-drop. Use SKE to the max extent possible for formation situational awareness.

- 24.13.3. NVG Takeoff. During an NVG takeoff, if the PF experiences NVG failure takeoff may be continued at the discretion of the aircraft commander; otherwise an abort will be initiated. Consider using the overt nose lights to continue the takeoff. If NVG malfunctions occur after Vgo, takeoff will be continued with the other pilot assuming control of the aircraft if necessary. If either pilot's NVGs fail after takeoff, continue the climbout and follow the appropriate procedures for loss of NVGs. Strong consideration should be given to continuing flight on autopilot.
- 24.13.4. Approach and Landing. If the pilot or copilot experience NVG failure or other malfunctions occur prior to touchdown, perform a go-around. If the PF's NVGs fail during or after touchdown, transfer control to the PNF for the landing rollout. Consider using the overt nose lights.
- **24.14. Aircraft Preparation.** The cockpit of the C-17A is specifically designed for NVG operations and little preparation is required for flights requiring NVGs. During exterior walk around inspection, a pilot will ensure all wheel well inspection lights are turned off and necessary exterior IR lighting is installed.
- 24.14.1. Loadmaster Aircraft Preparation. Taping of lights may be accomplished, however, no more than one layer of tape will be used. The Jump Signal Annunciators will not be taped. (EXCEPTION: For blacked-out or covert operations, a maximum of three layers of tape may be used. Jump Signal Annunciators will not be taped.)

NOTE: The use of mini-chemical lights or tape to mark/identify switches and/or equipment may be used as required.

This Page Intentionaly Left Blank

This Page Intentionaly Left Blank

This Page Intentionally Left Blank

Chapter 25

NAVAL EMERGENCY AIR CARGO DELIVERY SYSTEM (NEACDS)

25.1. General. NEACDS is designed for C-17 aircraft to airdrop emergency supplies to ships at sea.

25.2. NEACDS Operational Requirements.

- 25.2.1. C-17 crews will, as a minimum:
 - 25.2.1.1. Carry Navy Numerical Code (AMCS 608 NUCO) encode and decode tables and Navy voice call sign listing (AKAI 16 VSCL). Additional terms/codes are found in Joint Command Manual 55-200, AFR 3-16, and JCS Pub 1.
 - 25.2.1.2. Carry binoculars to aid in ship recognition.
 - 25.2.1.3. Carry operational brevity codes contained in Attachment 2 of this chapter.
- 25.2.2. Drop Zone (DZ). DZ selection, criteria, and markings for airdrop to land targets are not applicable for NEACDS. The target ship determines the DZ axis and point of impact (PI). Drop axis allows for downwind drop based on surface winds. The PI is determined on ship recovery capabilities but in no case will be closer than 500 yards abeam and 1,000 yards beyond target ship.
- 25.2.3. Restrictions include: radar altimeter must be operational prior to departure. If the objective area altimeter setting is unreliable or unavailable and the radar altimeter fails, the mission will be aborted. Radar must be operational prior to departure. Minimum drop altitudes are in accordance with AFI 11-231. Do not perform airdrops more than 1500 feet above ground level.
- 25.2.4. Prohibited operations: Multiple platform drops. (Airdrops of more than one platform or bundle per pass.), Overflight of ships with doors open, and formation drops.

25.3. Mission Planning.

- 25.3.1. Obtain the following information: Load configuration (number of loads, type load, load weight, and type parachutes); Drop altitude and airspeed; Forecast weather en route and in the objective area (includes cloud coverage and surface winds); Estimated drop axis; Rendezvous time; Minimum loiter time (loiter does not include search time); Maximum loiter time; Estimated ship's position at rendezvous time; Ship's state at rendezvous time (stationary or underway); Ship's description (call sign, type of ship, hull number, and photograph); Radio frequencies available (primary and secondary).
- 25.3.2. Use the fuel planning section, blocks 1 through 13, on AF Form 4081, Flight Plan and Record.
- 25.3.3. Fuel requirements. Complete AF Form 4081 except as follows:
 - 25.3.3.1. Item 1. Time and fuel from takeoff to overhead the target ship.
 - 25.3.3.2. Item 4. Use 20 minutes and 2,000 pounds of fuel.
- 25.3.3.3. Item 5 (loiter). Provide time between airdrops for ship retrieval efforts. Unless more time is specified, plan 30 minutes for the initial drop and for subsequent drops. For planning purposes, initial loiter begins 20 NM at 4,000 feet and includes the remaining descent and low level